

PART #173 1956-57

4-Door Hardtop Window Fur Channel Kit

Instruction Sheet Master

Revised 8/2018



Installation of Fur Strips (3/8" Flat Dusters)

1. Remove old staples by twisting up end and cutting off. If the original fur is no longer present look for remains of old staples or staple holes for more accurate location of fur strips.
2. On both front rear doors place new fur strip with the stainless bead up to the top edge of the door and interior garnish trim. On the rear doors there are 4-6 inch strips located below the upper strips (See "E" in diagram below). Use the original staple holes to help you locate correct positioning.
3. Hold fur and drill a 5/64" (.078) hole at one end, and progress towards the other end. Space holes about 6" apart. Using screws supplied in the kit to attach fur strip.
4. Hold fur and drill a 5/64" (.078) hole at one end, and progress towards the other end. Space holes closer on curved components. Using screws supplied to attach fur strip.

CAUTION: DO NOT start at each end and work towards the center. Drill each hole one at a time and install screw. This ensures more accurate alignment.

6. Twist heads of screws with screwdriver to sink it in fur pile. The head of the screw should draw into the pile enough so it becomes invisible.

Installation of Division Bar (Non-Flexible U-Channel)

1. The complete vent window assembly must be removed from the door. This is also a good time to replace the vent window seal, part #565.
2. The Division Bar Channel originally came in two pieces. The Division Bar Stops, part #147 should be replaced at this time. Ours is one piece to simplify installation.
3. Drill out four rivets holding the original fur channel. This will allow the top part of the assembly to come apart. Install the new Division Bar using hardware included in the screw kit.

Installation of Moleskin (Flat Strip of Fur)

1. The moleskin fits in the channel that is bolted to the back area of the door. The chrome window frame will slide up and down in it.
2. To install, remove old moleskin, degrease surface and apply glue. You can use part #036 - 3M Super Weatherstrip Adhesive.

Kit Includes:

- 2 - Division Bar Channels, 32" (A)
- 2 - 3/8 Exterior Fur Strips, 19-3/4" (B)
- 2 - 3/8 Interior Fur Strips, 18-3/4" (B)
- 2- Moleskin 18 x 1-5/8" Long (C)
- 2- 3/8 Exterior Fur Strips, 32-1/2" (D)
- 2 - 3/8 Interior Fur Strips, 30-1/2" (D)
- 4 - 3/8 Lower Fur Strips, 6" (E)
- 1 - Screw Kit

