



NOTE: If you are using this courtesy lamp kit in conjunction with a 1963 or 1964 Impala, you will need to cut the male blade terminal from the white door jamb switch wires and crimp on the "bullet style" terminals that have been provided loose piece in this 500471 kit.



**American
Autowire**

www.americanautowire.com 856-933-0801

Part 2 of Danchuk # 11204 Instructions

NOTE: Your new underdash courtesy lamp kit uses # 631 bulbs (not included with this kit). They may be purchased at any auto parts store.

PART #	N
500471	
DESCRIPTION:	<u>Courtesy Lamp Kit</u>
92965219	Rev 3.0 12/20/2019