



cut this template along dotted line

drill a 1/2" diameter mounting hole

drill a 1/2" diameter mounting hole

dash pad

firewall

fold this edge into door jamb cavity

FUSE PANEL MOUNTING HOLE TEMPLATE

driver's side kickpanel (metal area)



American Autowire

www.americanautowire.com 856-933-0801

Part 7 of Danchuk # 11204 Instructions

500433