



LIFELINE power wire routing

Danchuk # 15445

Installation Instructions

1. Connect the Remote Master Disconnect as per the instructions for the 500834 Remote Master Disconnect Kit
2. Connect the Remote Lifeline as per the diagram above.
3. Power leads for the battery side connections can be routed through the covering boot as shown in the enclosed diagram.



American Autowire / Factory-Fit
800-482-9473

