



INSTALLATION INSTRUCTIONS

1. Before attempting any modifications involving the charging system, disconnect the battery.
2. Unbolt the power lead wire from the existing alternator "BAT" post.
3. Unplug the 2 place voltage regulator connector from the old alternator.
4. Remove the old alternator from the car.
5. Install your new internally regulated alternator.
6. Plug the 2 place mating connector on the new 500295 alternator adapter wire into your existing two position connector just unplugged from the old alternator.
7. Plug the other end of this adapter into your new alternator.
8. Reconnect the power wire to the "BAT" post on the new alternator.
9. Make sure that the alternator is properly grounded. In most cases the alternator is grounded through the engine block to the frame and ultimately back to the battery. However, this is not always true. If in doubt, a ground wire can be installed from the alternator case ground bolt to a good chassis ground.
10. Reconnect the battery.



We Make Wiring Easy !

800-482-9473

Alternator Adapter Kit

GM SI series to
1994 and up GM CS130D

500295

92964773 instruction rev 7.0 7/7/2015

Danchuk # 17506