



**PLEASE** study these instructions carefully before beginning this installation. Most installations can be accomplished with common tools and procedures. However, you should be familiar with and comfortable working on your vehicle. If you do not feel comfortable performing this installation, it is recommended to have the installation completed by a qualified mechanic. If you have any questions, please call our **Technical Hotline at: 1-800-416-8628**, 7:00 am - 5:00 pm, Pacific Standard Time, Monday through Friday.

**IMPORTANT NOTE: Proper installation is the responsibility of the installer. Improper installation may result in poor performance and engine or vehicle damage.**

**INSTALLATION INSTRUCTIONS**

The #36054 Fuel Pump Relay Harness is required to operate any fuel pump, including the Edelbrock Fuel Sump, when running the Edelbrock E-Street TBI Fuel Injection. Damage to the E-Street ECU will occur if a fuel pump relay is not used or improperly installed.

The Fuel Pump Relay Harness connects between the Fuel Pump Connector on the E-Street EFI Harness and the Power Connector on the Fuel Pump Harness. The red power wire on the relay harness connects to a Constant +12v source.

