

PART #175 1955-57

4-Door Sedan Window Fur Channel Kit

Instruction Sheet Master

Revised 8/2018



Getting Ready for Installation of Fur Strips and Channels

1. Remove the old fur strips, cut the old staples and then start by twisting up end of fur and cutting off. Remove the flexible channels above the door glass and channels around rear quarter glass. After removal, clean out the slot with mineral spirits and a small wire brush if necessary. If the original fur is no longer present look for remains of old staples or staple holes for a more accurate location of fur strips.

Installation of Fur Strips (3/8" Flat Dusters)

1. On the interior and exterior side of the front doors note the fur strip has a straight end and a curved end. The straight end will be up by the division bar (See "C" in the diagram below). Use the original staple holes to help you locate the correct positioning of most of the fur strips.
2. On the interior body and exterior garnish moulding of the rear quarter align the fur to the body shape (See "D" in diagram below). Use the original staple holes to help you locate correct positioning of fur strips.
3. Hold the fur and drill a 5/64" (.078") hole at one end and progress towards the other end. Space holes about 6" apart. Use the screws supplied in kit to attach fur strip.

CAUTION: Do not start at each end and work towards center. Drill each hole one at a time and install screw. This insures more accurate alignment.

4. Twist heads of screws with screwdriver to sink it into the fur pile. The head of the screw should draw into the pile enough so it becomes invisible.

Installation of Division Bar (Non-flexible U-Channel)

1. The complete vent window assembly must be removed from the door. This is also a good time to replace the vent window seal, part #565A.
2. Drill out four rivets holding the original fur channel. This will allow the top part of the assembly to come apart. Install the new Division Bar, using hardware included in screw kit.

Installation of Flexible U-Channel

1. Before you start to install the flexible channel make sure the stainless beads will slide back and forth. This will allow the channel to bend without kinking. You can make small templates of the rounded corners of the glass out of a piece of thin plywood of similar thickness.
2. On the doors, after removing vent windows per instructions on page 1, slide the channel into the window opening. Make sure there is enough flexible channel down in front to fit into the new guide. You can drill through channel and into door frame. Install the screw. This will help hold it. Brush adhesive into the body channel and sides of the flexible channel. Slide the channel up into the corners. Use the template if you made one.
3. On the rear quarter glass slide the flexible channel into the glass opening. Make sure the channel is positioned correctly. See the diagram below for example. Do the same process as the doors to attach to the body. For positive mounting using small screws in corners will help. See diagram below.

Kit Includes:

- 2 - 32" Division Bar Channels (A)
- 4 - 3/8" x 20 Front Fur Strips (B)
- 2 - 48" Flexible Channels (C)
- 4 - 3/8" x 26-1/2" Front Fur Strips (D)
- 2 - 80-1/2" Flexible Channels (E)
- 1 - Screw Kit

