

PART #177 1955-57

Nomad Window Fur Channel Kit

Instruction Sheet Master



Revised 8/2018

Installation of Fur Strips (3/8" Flat Dusters)

1. Remove the old staples by twisting up the end and cutting it off. If the original fur is no longer present look for the remains of old staples or staple holes for a more accurate location of the fur strips.
2. On the front doors no fur strip was used on the interior side. A roller, part #14790, was used. Some did not have a fur strip on either side. Rollers were used. See part #14790 on the interior side and part #2082 on the exterior side. On vehicles with fur, place the new fur strips, located approximately 1-1/4" from the top edge of the door belt moulding, on the exterior door side. Use the original staple holes to help you locate the correct positioning. The fur strip was positioned low so no contact with the chrome window frame, part #15272, will accrue when the window is rolled down.
3. Hold the fur and drill a 5/64" (.078") hole at one end. Progress toward the other end. Space the holes about 6" apart. Use the screws supplied in the kit to attach the fur strip.
4. Hold fur and drill a 5/64" (.078") hole at one end and progress towards the other end. Space the holes closer on curved components. Use the screws supplied to attach fur strip.

CAUTION: Do not start at each end and work towards center. Drill each hole one at a time and install screw. This insures more accurate alignment.

6. Twist the heads of the screws with a screwdriver to sink it into the fur pile. The head of the screw should draw into the pile enough so that it becomes invisible.

Installation of the Division Bar (Non-flexible U-Channel)

1. The complete vent window assembly must be removed from the door. This is also a good time to replace the vent window seal, part #565.
2. The Division Bar Channel originally came in two pieces. The Division Bar Stops, part #147, should be replaced at this time. Our part is 1-piece to simplify installation.
3. Drill out four rivets holding the original fur channel. This will allow the top part of the assembly to come apart. Install the new Division Bar using the hardware included in the screw kit.

Installation of Moleskin (Flat Strip of Fur)

1. The Moleskin fits in the channel that is bolted to the back area of the door. The chrome window frame will slide up and down in it.
2. To install: remove old moleskin, degrease surface and apply glue. You can use 3M Super Weather-strip Adhesive, part #036.

Installation of the Flexible U-Channel

1. Before you start to install the flexible channel make sure the stainless beads will slide back and forth. This will allow the channel to bend without kinking.
2. Install the upper flexible channel by pushing it onto corner then attach it with screws. Now, install the lower strip into place. Drill through the channel and into the door frame. Install a screw to help hold it in place. Brush adhesive in the body channel and side of the flexible channel. Install the fur strip "F" onto the chrome stationary moulding. Part #1554, fur strip, is pre-installed. If you are missing some of the interior clips, you may need to order part #15026.

Kit Includes:

- 2 - 32" Division Bar Channels (A)
- 2 - 3/8" Front Fur Strips 25-1/4" (B)
- 2 - Moleskin 20 x 1-5/8" Long (C)
- 2 - 60" Flexible Channels (D)
- 2 - 45" Flexible Channels (E)
- 2 - 3/8" Slider Fur Strips 14" (F)
- 1 - Screw Kit

