


**NOTE:** This Mega-Fuse box should be mounted as close to the battery power source (junction block, starter relay, starter solenoid, etc.) as possible. AAW does NOT recommend installing this kit inside of the vehicle as the main power feed from the battery source to the Mega-Fuse is an unfused lead, and as such, should not be routed to the inside of your vehicle.



www.americanautowire.com 856-933-0801

PART # **500689**  
 DESCRIPTION:  
**MEGA-FUSE Kit -175 amp**  
 92965979 instruction sheet Rev 1.0 4/11/2013

**Part 1 of Danchuk # 12807 Instructions**



**NOTE:** This Mega-Fuse box should be mounted as close to the battery power source (junction block, starter relay, starter solenoid, etc.) as possible. AAW does NOT recommend installing this kit inside of the vehicle as the main power feed from the battery source to the Mega-Fuse is an unfused lead, and as such, should not be routed to the inside of your vehicle.



www.americanautowire.com 856-933-0801

PART # **500689**  
 DESCRIPTION:  
**MEGA-FUSE Kit -175 amp**  
 92965979 instruction sheet Rev 1.0 4/11/2013