

NOTE: This Mega-Fuse box should be mounted as close to the battery power source (junction block, starter relay, starter solenoid, etc.) as possible. AAW does NOT recommend installing this kit inside of the vehicle as the main power feed from the battery source to the Mega-Fuse is an unfused lead, and as such, should not be routed to the inside of your vehicle.



**American
Autowire**

www.americanautowire.com 856-933-0801


PART #

500689

DESCRIPTION:

MEGA-FUSE Kit -175 amp

92965979 instruction sheet Rev 1.0 4/11/2013



NOTE: This Mega-Fuse box should be mounted as close to the battery power source (junction block, starter relay, starter solenoid, etc.) as possible. AAW does NOT recommend installing this kit inside of the vehicle as the main power feed from the battery source to the Mega-Fuse is an unfused lead, and as such, should not be routed to the inside of your vehicle.



**American
Autowire**

www.americanautowire.com 856-933-0801

Part 11 of Danchuk # 17504 Instructions

PART #

500689

DESCRIPTION:

MEGA-FUSE Kit -175 amp

92965979 instruction sheet Rev 1.0 4/11/2013