





Headlight Bezels and Bezel Seals

INSTRUCTIONS



864 - Headlight Bezel Seals
Sold in pairs and may require trimming to fit.



This Rubber Extrusion is a copy of the original. See in the cutaway view shows the wire core.

This seal fits into Headlight Bezels and the small flap seals against the seal beam retaining ring. They may need to be trimmed to fit, install the seal starting center bottom of bezel. Cut to appropriate length using a pair cutting pliers.

Seal ends should just touch each other for best results.